

Light Curing Putty Instructions

The Light Curing Putty product from Phrozen is an easy material to use for repairing and restoring broken parts to their original shape. Please follow the instructions below on how to use the product.

Instructions

- 1) Clean the surface and remove any dust before applying putty.
- 2) Use the wooden stick to take out an appropriate amount and apply the putty.
- 3) Use alcohol to smoothen out the putty and clean the excess.
- 4) Use Phrozen Cure Beam or other curing lamps with LED wavelengths of 395 nm or above for 15–30 seconds.
- 5) For maximum result, cure putty at a 1cm distance to ensure that the light can enter through the bottom of the model.